How to Power wash and re-enroll a Chromebook

- 1. Make sure this chrome book is turned on. If not, then power on device.
- 2. Press **Esc** and **G** (refresh) and **power** buttons all at the same time. Release the **power** button, then wait for the next screen.


Please view below for power button locations:









3. You should now see a message that says. "Please insert a recovery USB stick or card." Press the ctrl + D keys at the same time.




4. Now you should see a message that says, "To turn OS verification Off, press Enter. Your system will reboot and local data will be cleared." Press the Enter key.




5. Now you should see a message that says, "OS verification is Off, press Space to reenable". Press the Space key.




6. Now you should see a message that says, "OS verification is Off, press Enter to confirm you wish to turn OS verification on. Your system will reboot and local data will be cleared." Press the Enter key.




7. Wait a few moments. When the Welcome screen appears click **Let's go**.




8. Connect to a Wi-Fi network. If you're in the district connect to BlueJayNet-Guest. If you're at home connect to your Wi-Fi network.




9. Review and agree Google's terms of service. Press Accept and continue when ready.




10. When the Enterprise Enrollment screen appears, enter your school email address, **username@sdowmo.org**. Then click on **Next**.



11. Now you should see the screen saying, "Enterprise enrollment is complete." Press **Done**.



12. Sign into your chrome book as you normally would.



If you have made it this far, then you have successfully power washed a chrome book.

